DWAU149X | smeg underbench dishwasher

ORBITAL WASH SYSTEM

Smeg's orbital wash system has two spray arms which operate simultaneously in opposite directions to ensure water is evenly distributed throughout the inner cavity for a perfect wash.

DELAY START TIMER

Delay Start option allows for up to 24-hours delay start — allowing you to take advantage of off-peak energy usage times.

TOTAL ACQUASTOP

Acquastop is a water safety device that operates when the dishwasher is not in operation by restricting mains pressure at the tap, and not at the dishwasher.

EAN	8017709151607
size	598mmW x 888mmH maximum x 570mmD
capacity	14 placesettings
finish	stainless steel door, silver control panel
programs	five — soak,normal ECO 45°C, ECO 50°C, intensive 65°C, Ultraclean
baskets	grey rilson upper: 3-level adjustment, EasyGlide lower: single tilting rack
wash system	orbital upper spray arm six wash directions
drying	natural condenser
timer	3-6-9 hour delay timer
filtration	5-stage water filtration system
safety	TOTAL ACQUASTOP LED on/off light end-cycle acoustic indicator self-balancing hinges
noise	45 dBA (when installed)
water	12.6 litres
power	1.9 kWh, 10 amps 230–240V, 50Hz

SAVE ON ENERGY AND PROTECT THE ENVIRONMENT

- always try to run the dishwasher full loaded
- do not wash dishes in running water
- use the washing program that is most appropriate for each type of load
- do not carry out any preliminary rinsing
- if available, connect the dishwasher to a hot water supply up to 60°C

The phosphates contained in dishwasher detergents are harmful to the environment. To avoid using excessive amounts of detergent and to save on electricity, observe the following:

- separate the more delicate items from dishes that are more resistant to aggressive detergents and high temperaures;
- do not pour the detergent directly onto the dishes.

DWAU149X | smeg underbench dishwasher



PLEASE NOTE: drawings are not to scale. They are to assist only.

PROGRAM	LOAD	PROGRAM PROGRESS	DURATION	CONSUMPTION	
			minutes	water litres	power kWh
SOAK	pans and dishes awaiting completion of load	cold prewash	15	3.5	0.02
NORMAL ECO	crockery and cutlery normally soiled	cold prewash wash at 45°C rinse at 45°C dry	147	12.6	0.71
ECO	dishes with normal dirt, with dried-on residue	cold prewash wash at 55°C cold rinse rinse at 70°C dry	100	11	1.3
INTENSIVE	dishes with normal dirt, with dried-on residue	cold prewash wash at 65°C cold rinse rinse at 70°C dry	115	13.5	1.35
ULTRACLEAN	very dirty pans and dishes, with dried-on residue	hot prewash wash at 70°C cold rinse rinse at 70°C dry	150	15.5	1.70

WARNING: technical specifications and product sizes can be varied by the manufacturer without notice. Cutouts for appliances should only be by physical product measurements. The above information is indicative only.